


# Panasonic®


## Operating Instructions

Projection Lens    Commercial Use

Model No. ET-D3LEU100  
ET-D3LEW200



ET-D3LEU100



ET-D3LEW200

ENGLISH

FRANÇAIS

日本語

### Read before use

This document is intended for the various projection lenses that can be attached to and used in conjunction with Panasonic projectors.

For Model No. and model names, refer to the product list (► page 4).

Thank you for purchasing this Panasonic product.

- To ensure correct use of this lens, please read the operating instructions supplied with the lens and the projector carefully.
- **Before using this product, be sure to read “Read this first!” (►Page 3).**
- Please save this manual for future use.

# Contents

|   |                          |
|---|--------------------------|
| <b>Read this first!</b>                             | 3                        |
| <b>Before Use</b>                                   | 4                        |
| <b>Preparation</b>                                  | 5                        |
| Before replacing the projection lens                | 5                        |
| Attaching and Detaching the Lens                    | 5                        |
| Peripheral focus adjustment function                | 6                        |
| Lens calibration                                    | 7                        |
| <b>Projection relationships</b>                     | 10                       |
| <b>Lens shift ranges</b>                            | 12                       |
| <b>Specifications</b>                               | 14                       |
| <b>Dimensions</b>                                   | 14                       |
| <b>Projected image size and Projection distance</b> | Appendix / Annexe / 付録 1 |

The "Appendix" can be found after the Japanese language section (日本語).

# Read this first!

Always follow these precautions

## **WARNING:**

**Do not look at or place your skin into the light emitted from the lens while the projector is being used.**

Doing so can cause burns or loss of sight.

- Strong light is emitted from the projector's lens. Do not look at or place your hands directly into this light.

- Turn off the power when moving away from the projection lens or projector.

**Do not project an image with the lens cover attached.**

- Doing so can cause fire.

## **CAUTION:**

**Before replacing the projection lens, be sure to turn off the power and disconnect the power plug from the wall outlet.**

- Unexpected projection of light may cause injury to eyes.

- Replacing the projection lens without removing the power plug may result in electric shock.

**Do not stand in front of the lens while the projector is being used.**

Doing so can cause damage and burns to clothing.

- Strong light is emitted from the projector's lens.

**Do not place objects in front of the lens while the projector is being used.**

Doing so can cause fire, damage to the object, or malfunction of the lens and projector.

- Strong light is emitted from the projector's lens.

**Do not open the desiccant bag. Do not eat the contents.**

Inadvertently ingesting desiccant could be harmful.

- If the desiccant gets into your eyes or mouth, immediately rinse with plenty of water and seek medical attention.

- Keep desiccant out of the reach of children.

# Before Use

## ■ Product list

The product names and model numbers of the projection lenses covered by this manual are as follows.

| Product name     | Model number | Description  |
|------------------|--------------|--|
| Fixed-focus lens | ET-D3LEU100  | Projection lens equipped with an EEPROM <sup>1</sup> .                   |
| Zoom lens        | ET-D3LEW200  | Projection lens equipped with an EEPROM <sup>1</sup> and stepping motor. |

\*1 EEPROM: Electrically erasable programmable read-only memory

## ■ Projectors supported by each projection lens

ET-D3LEU100:

PT-RQ32K / PT-RZ31K / PT-RS30K / PT-RQ22K / PT-RZ21K / PT-RS20K /  
PT-RQ13K / PT-RZ12K / PT-RS11K / PT-DZ21K2 / PT-DS20K2 / PT-DW17K2 /  
PT-DZ16K2 / PT-DZ13K / PT-DS12K / PT-DW11K / PT-DZ10K

ET-D3LEW200:


PT-RQ32K / PT-RZ31K / PT-RS30K / PT-RQ22K / PT-RZ21K / PT-RS20K

### Note

- Some of the alphabet letters at the end of projector model numbers may be omitted in this manual.
- Models other than the above may also be supported. Refer to the operating instructions for your projector or the Panasonic website (<https://panasonic.net/cns/projector/>).
- If the projector you are using is PT-RQ32K / PT-RZ31K / PT-RS30K / PT-RQ22K / PT-RZ21K / PT-RS20K, you may not be able to use the projection lens depending on main version of the firmware. If main version of the firmware is the version number shown below, update to the latest firmware before use.
  - PT-RQ32K: Earlier than 3.16
  - PT-RZ31K / PT-RS30K: Earlier than 3.09
  - PT-RQ22K: Earlier than 1.05
  - PT-RZ21K / PT-RS20K: Earlier than 2.07
- For details on the update procedure, refer to the latest firmware information on the Panasonic website (<https://panasonic.net/cns/projector/pass/>).
- The main version of the firmware can be checked in the [STATUS] screen.

## ■ Supplied Accessories

Make sure that the following has been provided.

| Part name  | Appearance  |   |
|------------|---|---|
| Lens cover |  | <ul style="list-style-type: none"><li>● The product is delivered with a lens cover attached.</li><li>● The shape and size of the lens caps are different for each product.</li></ul> <p>1 each for front and rear</p> |

# Preparation

## Before replacing the projection lens

Return the projection lens to the home position before replacing or removing it.

For details on how to return the lens to the home position, refer to the operating instructions of the projector.

### Attention

- Make sure that the projector power supply is switched off before attaching or detaching the projection lens.
- After removing the projection lens, store it safely away from vibration or impacts.
- Do not touch the electrical contacts of the projection lens with your fingers. Dust and dirt on the contacts may cause contact malfunctions, while static electricity may damage the unit.
- Do not touch the surface of the lens with bare hands. Finger prints and dirt on the surface of the lens will be magnified by the lens and lower the quality of the projected image. Place the supplied lens cover on the zoom lens when the projector is not in use.
- The lens is made of glass. The lens could be damaged if brought into contact with or rubbed against hard objects. Handle the lens carefully.
- Use a clean, soft and dry cloth to wipe away dust and dirt from the projection lens. Do not use fluffy cloths containing oil, water or dust for cleaning. The lens is easily damaged, so do not apply excessive pressure when wiping it.
- Use of the ET-PLF20 lens fixed attachment is recommended. However, it does not support PT-DZ21K2 / PT-DS20K2 / PT-DW17K2 / PT-DZ16K2 / PT-DZ13K / PT-DS12K / PT-DW11K / PT-DZ10K projectors.
- The ET-PLF10 lens fixed attachment cannot be used.
- When using the ET-PLF20 lens fixed attachment, it may not be possible to attach the mounting brackets of the attachment without returning the lens to the home position.

## Attaching and Detaching the Lens


For details on attaching and detaching the projection lens, refer to the operating instructions of the projector.

## Preparation (continued)

### Peripheral focus adjustment function


When you change the size of the projected image, the focal balance between the center and peripheral areas of the screen may shift. This shift in balance tends to increase proportionally with smaller throw ratios.

The ET-D3LEU100 / ET-D3LEW200 is equipped with a peripheral focus adjustment function to correct the shift in focal balance between the center and peripheral areas of the screen.



The illustrations in this procedure depict attachment of the ET-D3LEU100 onto the PT-RZ21K.

#### ■ Adjusting the focus



- 1) Turn the peripheral focus adjustment ring in the direction of the arrow to match the projection distance displayed on the lens to the actual distance from the lens to the screen.
- 2) Operate the projector to align the focus of the center of the projected image.

#### Note

- The projection distances displayed on the lens are approximate guides.
- The lens focus is not stable immediately after powering on due to the effect of heat produced by the light source.  
It is recommended that the focus be adjusted after the image has been projected for approximately 1 hour.

# Preparation (continued)

## Lens calibration

Perform lens calibration after attaching the lens.

The lens calibration procedure differs depending on the projector you are using and the main version of the firmware.

- **PT-RQ32K / PT-RZ31K / PT-RS30K / PT-RQ22K / PT-RZ21K / PT-RS20K**  
Refer to "Case 1" (► page 7).
- **PT-RQ13K / PT-RZ12K / PT-RS11K / PT-DZ21K2 / PT-DS20K2 / PT-DW17K2 / PT-DZ16K2 / PT-DZ13K / PT-DS12K / PT-DW11K / PT-DZ10K**  
Refer to "Case 2" (► page 9).

### Case 1

- PT-RQ32K (main version of the firmware is 3.16 or later)
- PT-RZ31K / PT-RS30K (main version of the firmware is 3.09 or later)
- PT-RQ22K (main version of the firmware is 1.05 or later)
- PT-RZ21K / PT-RS20K (main version of the firmware is 2.07 or later)


The illustrations in this procedure depict use of the ET-D3LEW200 as an example.

| PROJECTOR SETUP      |             |
|----------------------|-------------|
| PROJECTOR ID         | ALL         |
| PROJECTION METHOD    |             |
| LENS                 |             |
| OPERATION SETTING    | NORMAL      |
| LIGHT OUTPUT         | 100.0%      |
| BRIGHTNESS CONTROL   | AUTO        |
| STANDBY MODE         | NORMAL      |
| NO SIGNAL SHUT-OFF   | DISABLE     |
| NO SIGNAL LIGHTS-OUT | DISABLE     |
| INITIAL STARTUP      | LAST MEMORY |
| STARTUP INPUT SELECT | LAST USED   |
| DATE AND TIME        |             |
| ◀ MENU SELECT        |             |
| ENTER                | SUB MENU    |

| LENS                     |             |
|--------------------------|-------------|
| LENS TYPE                | ET-D3LEW200 |
| LENS INFORMATION SETTING |             |
| LENS MEMORY              |             |
| LENS HOME POSITION       |             |
| ACTIVE FOCUS OPTIMIZER   |             |
| LENS CALIBRATION         |             |
| ◀ MENU SELECT            |             |
| ENTER                    | SUB MENU    |


- 1) Press the <MENU> button.
- 2) Use the ▲ and ▼ buttons to select [PROJECTOR SETUP], and press the <ENTER> button.
  - The [PROJECTOR SETUP] screen appears.
- 3) Use the ▲ and ▼ buttons to select [LENS], and press the <ENTER> button.
  - The [LENS] screen appears.
- 4) Use the ▲ and ▼ buttons to select [LENS CALIBRATION], and press the <ENTER> button.
  - The [LENS CALIBRATION] screen appears.
  - When the ET-D3LEU100 is attached, a confirmation screen appears when the <ENTER> button is pressed. In such cases, proceed to step 6.

## Preparation (continued)



- 5) Use the ▲ and ▼ buttons to select [SHIFT/FOCUS/ZOOM], and press the <ENTER> button.

- The confirmation screen appears. (ET-D3LEW200 only)



- 6) Use the ◀ and ▶ buttons to select [OK], and press the <ENTER> button.

- Lens calibration starts.
- The projection lens moves to the home position after adjustment range calibration is complete.




### Note

- If lens calibration is not performed, the available zoom range of the ET-D3LEW200 will become narrowed.
- If ET-D3LEU100 is used on the PT-RQ32K / PT-RZ31K / PT-RS30K, part of the image will be obscured when in the home position. Adjust the lens shift within the lens shift range as described on page 12.

## Preparation (continued)

### ■ Case 2

- PT-RQ13K / PT-RZ12K / PT-RS11K
- PT-DZ21K2 / PT-DS20K2 / PT-DW17K2 / PT-DZ16K2
- PT-DZ13K / PT-DS12K / PT-DW11K / PT-DZ10K



#### Note

- If ET-D3LEU100 is used on the PT-DZ21K2 / PT-DZ16K2, part of the image will be obscured when in the home position. Adjust the lens shift within the lens shift range as described on page 12.

- 1) Press the <MENU> button.
- 2) Use the ▲ and ▼ buttons to select [PROJECTOR SETUP], and press the <ENTER> button.

- The [PROJECTOR SETUP] screen appears.

- 3) Use the ▲ and ▼ buttons to select [LENS CALIBRATION].
- 4) Use the ◀ and ▶ buttons to select [NORMAL], and press the <ENTER> button.

- The confirmation screen appears.


- 5) Use the ◀ and ▶ buttons to select [OK], and press the <ENTER> button.

- Lens calibration starts.
- The projection lens moves to the home position after adjustment range calibration is complete.

# Projection relationships

The dimensional relationship between the screen and the projector is shown below.

## ■ Dimensional relationship diagram



### Note

- This diagram assumes that the size and position of the projected image will be adjusted so that the image fills the entire screen.
- This illustration is not drawn to scale.

|    |  |
|----|--|
| L  | Projection distance                                |
| LW | Minimum distance                                   |
| LT | Maximum distance                                   |
| L1 | Distance from front of projector to edge of lens   |
| L2 | Distance from front of projector to center of lens |
| L3 | Distance from side of projector to center of lens  |
| SH | Projected image height                             |
| SW | Projected image width                              |
| SD | Projected image size                               |

### ● Dimension for L1 (approximate values)

(Unit: m)

| Projector model                               | Dimension for L1<br>(approximate value) |             |
|---|---|-------------|
|   | ET-D3LEU100                             | ET-D3LEW200 |
| PT-RQ32K / PT-RZ31K / PT-RS30K                | 0.26                                    | 0.32        |
| PT-RQ22K / PT-RZ21K / PT-RS20K                |   | 0.35        |
| PT-RQ13K / PT-RZ12K / PT-RS11K                |   | -           |
| PT-DZ21K2 / PT-DS20K2 / PT-DW17K2 / PT-DZ16K2 | 0.29                                    | -           |
| PT-DZ13K / PT-DS12K / PT-DW11K / PT-DZ10K     |   | -           |

## Projection relationships (continued)

### ● Dimension for L2 (approximate values)

(Unit: m)

| Projector model                               | Dimension for L2<br>(approximate value) |             |
|---|---|-------------|
|   | ET-D3LEU100                             | ET-D3LEW200 |
| PT-RQ32K / PT-RZ31K / PT-RS30K                | 0.18                                    | 0.23        |
| PT-RQ22K / PT-RZ21K / PT-RS20K                |   | 0.26        |
| PT-RQ13K / PT-RZ12K / PT-RS11K                |   | -           |
| PT-DZ21K2 / PT-DS20K2 / PT-DW17K2 / PT-DZ16K2 | 0.21                                    | -           |
| PT-DZ13K / PT-DS12K / PT-DW11K / PT-DZ10K     |   | -           |


### ● Dimension for L3 (approximate values)

(Unit: m)

| Projector model                               | Dimension for L3<br>(approximate value) |             |
|---|---|-------------|
|   | ET-D3LEU100                             | ET-D3LEW200 |
| PT-RQ32K / PT-RZ31K / PT-RS30K                | 0.15                                    | 0.18        |
| PT-RQ22K / PT-RZ21K / PT-RS20K                | 0.10                                    | 0.13        |
| PT-RQ13K / PT-RZ12K / PT-RS11K                | 0.09                                    | -           |
| PT-DZ21K2 / PT-DS20K2 / PT-DW17K2 / PT-DZ16K2 | 0.11                                    | -           |
| PT-DZ13K / PT-DS12K / PT-DW11K / PT-DZ10K     | 0.07                                    | -           |

### Note

- The illustrations of projectors in this manual are for informational purposes only and do not represent a specific projector model. Configurations may vary with the model.
- If the screen is tilted downward, extend the adjustable feet on the sides of the projector until the projected image is rectangular.  
If the projector is inclined horizontally, adjust the adjustable feet until the projector is level. You can extend the adjustable feet by turning them as shown in the diagram. To return the feet to the original position, turn them in the opposite direction.



### Attention

- To prevent obstruction of the intake and exhaust vents, install the projector with a clearance at least 500 mm (1 ft. 7 in.) from walls and objects.  
If you are installing the projector in a sealed space, be sure to provide additional air conditioning equipment and ventilation equipment. Insufficient ventilation will result in an accumulation of heat and may activate the projector's protection circuit.
- Avoid setting up in places which are subject to sudden temperature changes, such as near an air conditioner or lighting equipment (studio lamps, etc.).

### ■ Dimensional relationship

For details on the projection distance (L), refer to "Projected image size and Projection distance" and "Projection distance formulas" in the Appendix.

# Lens shift ranges

After moving the lens to the home position according to "Lens calibration" on page 7, you can use the position of the projected image at that position (i.e., the standard projection position) as a basis, and use the lens shift adjustment function on the projector to adjust the position of the projected image within the respective lens shift ranges.

Perform lens shift adjustment within the ranges shown in the following illustrations.


Moving the lens outside of the adjustment ranges may alter the focus. This occurs due to limitations in lens movement that are intended to protect the optical components.

The following illustrations depict lens shift ranges for floor installations of the projector.


## ● ET-D3LEU100

| Projector model | A    | B    | b    | x    |
|-----------------|------|------|------|------|
| PT-RZ31K        | 0.25 | 0.24 | 0.12 | 0.18 |
| PT-DZ21K2       |      | 0.45 |      | 0.05 |
| PT-RQ32K        | 0.29 | 0.35 | 0.15 | 0.15 |
| PT-RS30K        | 0.3  | 0.3  | 0.1  | 0.15 |
| PT-DZ16K2       | 0.2  | 0.48 | 0.15 | 0.05 |

\* Part of the image will be obscured when in the home position.




| Projector model | A    | B    | b    | y    | z    |
|-----------------|------|------|------|------|------|
| PT-RZ21K        | 0.25 | 0.55 | 0.12 | 0    | 0.55 |
| PT-RZ12K        |      |      |      | 0.05 | 0.45 |
| PT-DZ13K        |      |      |      | 0.18 | 0.24 |
| PT-DZ10K        |      |      |      | 0.18 | 0.24 |
| PT-RQ22K        | 0.29 | 0.59 | 0.15 | 0.05 | 0.5  |
| PT-RQ13K        |      |      |      | 0.09 | 0.45 |
| PT-RS20K        | 0.3  | 0.5  | 0.1  | 0.05 | 0.43 |
| PT-RS11K        |      |      |      | 0.05 | 0.43 |
| PT-DS12K        |      |      |      | 0.25 | 0.15 |
| PT-DS20K2       |      |      |      | 0    | 0.5  |
| PT-DW17K2       | 0.3  | 0.7  | 0.2  | 0    | 0.7  |
| PT-DW11K        |      |      |      | 0.27 | 0.25 |




## Lens shift ranges (continued)

### ● ET-D3LEW200

| Projector model | A    | B    | b    | y    | z    |
|-----------------|------|------|------|------|------|
| PT-RZ31K        | 0.15 | 0.48 | 0.12 | 0.05 | 0.35 |
| PT-RQ32K        | 0.19 | 0.56 | 0.24 | 0.1  | 0.39 |
| PT-RS30K        | 0.18 | 0.4  | 0.12 | 0.14 | 0.18 |



| Projector model | A    | B    | b    |
|-----------------|------|------|------|
| PT-RZ21K        | 0.15 | 0.48 | 0.12 |
| PT-RQ22K        | 0.19 | 0.56 | 0.24 |
| PT-RS20K        | 0.18 | 0.4  | 0.12 |



### Note

- The home position of the projector is a point of origin position for the lens shift (i.e., vertical and horizontal positions of the lens) based on the results of lens calibration. It is not the optical center position of the screen.

# Specifications

Check the specifications of each projection lens, and use the appropriate lens for your intended use.

| Model No.             | ET-D3LEU100              | ET-D3LEW200                         |
|-----------------------|--------------------------|-------------------------------------|
| F value               | 2.5                      | 2.5                                 |
| Focal Length (f)      | 8.0 mm (5/16")           | 13.8 mm (17/32") - 18.1 mm (23/32") |
| Supported screen size | 200" to 600"             |                                     |
| Dimensions            | Width                    | 275 mm (10-13/16")                  |
|                       | Height                   | 154 mm (6-1/16")                    |
|                       | Depth                    | 428.7 mm (16-7/8")                  |
| Net Weight            | Approx. 8.0 kg (17.6 lb) | Approx. 9.0 kg (19.8 lb)            |

# Dimensions

(Unit: mm)

| Model number | Dimensions   |
|--------------|--|
| ET-D3LEU100  | <p>The technical drawing illustrates the physical dimensions of the ET-D3LEU100 lens. The front view shows a circular lens element with a diameter of <math>\varnothing 152</math> (5-31/32"). The side view shows the total height of the lens as 275 (10-13/16") and the distance from the front surface to the center of the lens body as 198 (7-25/32"). The overall length of the lens body is 428.7 (16-7/8"), and the distance from the rear of the lens body to the projection point is 352.7 (13-7/8").</p> |

## Dimensions (continued)

| Model number | Dimensions   |
|--------------|--|
| ET-D3LEW200  | <p>The technical drawing illustrates the physical dimensions of the ET-D3LEW200 unit. It features two views: a front view showing height and width, and a side view showing depth and a flange dimension. Key dimensions are:</p> <ul style="list-style-type: none"><li>Front View:<ul style="list-style-type: none"><li>Total height: 250 (9-27/32")</li><li>Front base height: 173 (6-13/16")</li><li>Total width: 398.5 (15-11/16")</li><li>Total depth: 495.0 (19-1/2")</li></ul></li><li>Side View:<ul style="list-style-type: none"><li>Flange diameter: Ø 193 (7-19/32")</li><li>Total depth: Ø 154 (6-1/16")</li></ul></li></ul> |

#### **Information for users in the European Union**

Importer's name and address within the European Union  
Panasonic Marketing Europe GmbH  
Panasonic Testing Centre  
Winsbergring 15, 22525 Hamburg, Germany

#### **Disposal of Old Equipment**

##### **Only for European Union and countries with recycling systems**



This symbol on the products, packaging, and/or accompanying documents means that used electrical and electronic products must not be mixed with general household waste.

For proper treatment, recovery and recycling of old products, please take them to applicable collection points in accordance with your national legislation.

By disposing of them correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment.

For more information about collection and recycling, please contact your local municipality. Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.

#### **Information on Disposal in other Countries outside the European Union**

This symbol is only valid in the European Union.

If you wish to discard this product, please contact your local authorities or dealer and ask for the correct method of disposal.

#### **Product Information (for Turkey only)**



AEEE Yönetmeliğine Uygundur.

Eski Ekipman ve Bataryaların İşlenmesi.

Sadece geri dönüşüm sistemleri olan Avrupa Birliği ve ülkeler için geçerlidir.

Ürünler, ambalaj ve/veya ekli belgeler üzerindeki bu semboller kullanılmış elektrik ve elektronik ürünlerin genel ev atığı ile karıştırılmaması gerektiğini ifade eder.

Eski ürünlerin toplanması ve geri kazanılması için bu atıklar lütfen yasaya belirlenmiş olan uygun toplama merkezlerine teslim ediniz.

Bu atıkların doğru işlenmesiyle, değerli kaynakların korunmasına ve insan sağlığı ve çevreye olası negatif etkilerinin engellenmesine yardımcı olabilirsiniz.

Atıkların toplanması ve geri dönüşümü için detaylı bilgi için lütfen bağlı olduğunuz yerel yönetimlerle iletişime geçiniz.

Atıkların atılmasıyla ilgili yanlış uygulamalar yasaya belirlenmiş olan cezalara sebebiyet verebilir.

# **Panasonic Corporation**

Web Site : <https://panasonic.net/cns/projector/>

© Panasonic Corporation 2019

## **Panasonic System Solutions Company of North America**

Two Riverfront Plaza, Newark, NJ 07102

TEL: (877) 803 - 8492

## **Panasonic Canada Inc.**

5770 Ambler Drive, Mississauga, Ontario L4W 2T3

TEL: (905) 624 - 5010

HS0719AM0 -PS

**Printed in Japan**

# Appendix / Annexe / 付録

- Projected image size and Projection distance
- Taille de l'image projetée et Distance de projection
- 投写画面サイズと投写距離

## ● ET-D3LEU100

(Unit / Unités / 単位 : m)

When the screen aspect ratio is 16:9  
Lorsque le rapport d'aspect de l'écran est 16:9  
アスペクト比 16:9

PT-RQ22K / PT-RQ32K / PT-RQ13K  
Throw ratio / Rapport de projection /  
スローレシオ : [0.397:1]

PT-RZ21K / PT-RZ31K / PT-RZ12K /  
PT-DZ21K2 / PT-DZ13K / PT-DZ10K  
Throw ratio / Rapport de projection /  
スローレシオ : [0.370:1]

| SD           | SH    | SW     | L    | L    |
|--------------|-------|--------|------|------|
| 5.08 (200")  | 2.692 | 4.308  | 1.71 | 1.59 |
| 6.35 (250")  | 3.365 | 5.385  | 2.12 | 2.01 |
| 7.62 (300")  | 4.039 | 6.462  | 2.56 | 2.42 |
| 8.89 (350")  | 4.712 | 7.539  | 3.11 | 2.84 |
| 10.16 (400") | 5.385 | 8.616  | 3.55 | 3.25 |
| 12.70 (500") | 6.731 | 10.770 | 4.44 | 4.08 |
| 15.24 (600") | 8.077 | 12.923 | 5.33 | 4.91 |

When the screen aspect ratio is 16:9  
Lorsque le rapport d'aspect de l'écran est 16:9  
アスペクト比 16:9

PT-RQ22K / PT-RQ32K / PT-RQ13K  
Throw ratio / Rapport de projection /  
スローレシオ : [0.398:1]

PT-RZ21K / PT-RZ31K / PT-RZ12K /  
PT-DZ21K2 / PT-DZ13K / PT-DZ10K  
Throw ratio / Rapport de projection /  
スローレシオ : [0.370:1]

| SD           | SH    | SW     | L    | L    |
|--------------|-------|--------|------|------|
| 5.08 (200")  | 2.491 | 4.428  | 1.76 | 1.64 |
| 6.35 (250")  | 3.113 | 5.535  | 2.18 | 2.06 |
| 7.62 (300")  | 3.736 | 6.641  | 2.63 | 2.49 |
| 8.89 (350")  | 4.358 | 7.748  | 3.20 | 2.92 |
| 10.16 (400") | 4.981 | 8.855  | 3.65 | 3.34 |
| 12.70 (500") | 6.226 | 11.069 | 4.56 | 4.19 |
| 15.24 (600") | 7.472 | 13.283 | 5.48 | 5.05 |

PT-RS20K / PT-RS30K /  
PT-RS11K / PT-DS20K2 /  
PT-DS12K  
Throw ratio /  
Rapport de projection /  
スローレシオ : [0.402:1]

PT-DW17K2 /  
PT-DW11K  
Throw ratio /  
Rapport de projection /  
スローレシオ :  
[0.413:1]

PT-DZ16K2  
Throw ratio /  
Rapport de projection /  
スローレシオ :  
[0.370:1]

| SD           | SH    | SW     | L    | L    | L    |
|--------------|-------|--------|------|------|------|
| 5.08 (200")  | 2.491 | 4.428  | 1.78 | 1.82 | 1.64 |
| 6.35 (250")  | 3.113 | 5.535  | 2.24 | 2.30 | 2.06 |
| 7.62 (300")  | 3.736 | 6.641  | 2.70 | 2.77 | 2.49 |
| 8.89 (350")  | 4.358 | 7.748  | 3.16 | 3.24 | 2.92 |
| 10.16 (400") | 4.981 | 8.855  | 3.62 | 3.72 | 3.34 |
| 12.70 (500") | 6.226 | 11.069 | 4.55 | 4.66 | 4.19 |
| 15.24 (600") | 7.472 | 13.283 | 5.47 | 5.61 | 5.05 |

## Appendix / Annexe / 付録 (continued / suite / つづき)

(Unit / Unités / 単位 : m)

When the screen aspect ratio is 4:3  
Lorsque le rapport d'aspect de l'écran est 4:3  
アスペクト比 4:3

|   |  |
|---|--|
| PT-RQ22K / PT-RQ32K / PT-RQ13K<br>Throw ratio / Rapport de projection /<br>スローレシオ : [0.479:1] | PT-RZ21K / PT-RZ31K / PT-RZ12K /<br>PT-DZ21K2 / PT-DZ13K / PT-DZ10K<br>Throw ratio / Rapport de projection /<br>スローレシオ : [0.446:1] |
|---|--|

| SD           | SH    | SW     | L    | L    |
|--------------|-------|--------|------|------|
| 5.08 (200")  | 3.048 | 4.064  | 1.94 | 1.81 |
| 6.35 (250")  | 3.810 | 5.080  | 2.45 | 2.28 |
| 7.62 (300")  | 4.572 | 6.096  | 2.95 | 2.75 |
| 8.89 (350")  | 5.334 | 7.112  | 3.45 | 3.22 |
| 10.16 (400") | 6.096 | 8.128  | 3.96 | 3.69 |
| 12.70 (500") | 7.620 | 10.160 | 4.96 | 4.63 |
| 15.24 (600") | 9.144 | 12.192 | 5.97 | 5.56 |

|   |  |  |
|---|--|--|
| PT-RS20K / PT-RS30K /<br>PT-RS11K / PT-DS20K2 /<br>PT-DS12K<br>Throw ratio /<br>Rapport de projection /<br>スローレシオ : [0.401:1] | PT-DW17K2 /<br>PT-DW11K<br>Throw ratio /<br>Rapport de projection /<br>スローレシオ :<br>[0.554:1] | PT-DZ16K2<br>Throw ratio /<br>Rapport de projection /<br>スローレシオ :<br>[0.497:1] |
|---|--|--|

| SD           | SH    | SW     | L    | L    | L    |
|--------------|-------|--------|------|------|------|
| 5.08 (200")  | 3.048 | 4.064  | 1.63 | 2.25 | 2.02 |
| 6.35 (250")  | 3.810 | 5.080  | 2.05 | 2.83 | 2.54 |
| 7.62 (300")  | 4.572 | 6.096  | 2.47 | 3.41 | 3.06 |
| 8.89 (350")  | 5.334 | 7.112  | 2.90 | 3.99 | 3.58 |
| 10.16 (400") | 6.096 | 8.128  | 3.32 | 4.56 | 4.10 |
| 12.70 (500") | 7.620 | 10.160 | 4.17 | 5.72 | 5.15 |
| 15.24 (600") | 9.144 | 12.192 | 5.01 | 6.88 | 6.19 |

## Appendix / Annexe / 付録 (continued / suite / つづき)

### ● ET-D3LEW200

When the screen aspect ratio is 16:10

Lorsque le rapport d'aspect de l'écran est 16:10

アスペクト比 16:10

(Unit / Unités / 単位 : m)

| SD           | SH    | SW     | PT-RQ22K / PT-RQ32K<br>Throw ratio / Rapport de projection /<br>スローレシオ : [0.693 - 0.913:1] |       | PT-RZ21K / PT-RZ31K<br>Throw ratio / Rapport de projection /<br>スローレシオ : [0.645 - 0.850:1] |       |
|--------------|-------|--------|--|-------|--|-------|
|              |       |        | LW   | LT    | LW   | LT    |
| 5.08 (200")  | 2.692 | 4.308  | 2.98   | 3.93  | 2.78   | 3.66  |
| 6.35 (250")  | 3.365 | 5.385  | 3.75   | 4.94  | 3.50   | 4.61  |
| 7.62 (300")  | 4.039 | 6.462  | 4.53   | 5.95  | 4.22   | 5.55  |
| 8.89 (350")  | 4.712 | 7.539  | 5.30   | 6.96  | 4.94   | 6.49  |
| 10.16 (400") | 5.385 | 8.616  | 6.07   | 7.98  | 5.66   | 7.44  |
| 12.70 (500") | 6.731 | 10.770 | 7.61   | 10.00 | 7.09   | 9.32  |
| 15.24 (600") | 8.077 | 12.923 | 9.15   | 12.02 | 8.53   | 11.21 |

When the screen aspect ratio is 16:9

Lorsque le rapport d'aspect de l'écran est 16:9

アスペクト比 16:9

(Unit / Unités / 単位 : m)

| SD           | SH    | SW     | PT-RQ22K / PT-RQ32K<br>Throw ratio /<br>Rapport de projection /<br>スローレシオ :<br>[0.694 - 0.913:1] |       | PT-RZ21K / PT-RZ31K<br>Throw ratio /<br>Rapport de projection /<br>スローレシオ :<br>[0.646 - 0.851:1] |       | PT-RS20K / PT-RS30K<br>Throw ratio /<br>Rapport de projection /<br>スローレシオ :<br>[0.701 - 0.923:1] |       |
|--------------|-------|--------|--|-------|--|-------|--|-------|
|              |       |        | LW   | LT    | LW   | LT    | LW   | LT    |
| 5.08 (200")  | 2.491 | 4.428  | 3.07   | 4.05  | 2.86   | 3.77  | 3.10   | 4.09  |
| 6.35 (250")  | 3.113 | 5.535  | 3.86   | 5.08  | 3.60   | 4.74  | 3.90   | 5.14  |
| 7.62 (300")  | 3.736 | 6.641  | 4.65   | 6.12  | 4.34   | 5.71  | 4.70   | 6.19  |
| 8.89 (350")  | 4.358 | 7.748  | 5.45   | 7.16  | 5.08   | 6.68  | 5.50   | 7.24  |
| 10.16 (400") | 4.981 | 8.855  | 6.24   | 8.20  | 5.82   | 7.65  | 6.30   | 8.29  |
| 12.70 (500") | 6.226 | 11.069 | 7.82   | 10.28 | 7.29   | 9.58  | 7.91   | 10.38 |
| 15.24 (600") | 7.472 | 13.283 | 9.41   | 12.35 | 8.77   | 11.52 | 9.51   | 12.48 |

When the screen aspect ratio is 4:3

Lorsque le rapport d'aspect de l'écran est 4:3

アスペクト比 4:3

(Unit / Unités / 単位 : m)

| SD           | SH    | SW     | PT-RQ22K / PT-RQ32K<br>Throw ratio /<br>Rapport de projection /<br>スローレシオ :<br>[0.835 - 1.09:1] |       | PT-RZ21K / PT-RZ31K<br>Throw ratio /<br>Rapport de projection /<br>スローレシオ :<br>[0.778 - 1.02:1] |       | PT-RS20K / PT-RS30K<br>Throw ratio /<br>Rapport de projection /<br>スローレシオ :<br>[0.699 - 0.921:1] |       |
|--------------|-------|--------|---|-------|---|-------|--|-------|
|              |       |        | LW  | LT    | LW  | LT    | LW   | LT    |
| 5.08 (200")  | 3.048 | 4.064  | 3.39  | 4.47  | 3.16  | 4.16  | 2.84   | 3.75  |
| 6.35 (250")  | 3.810 | 5.080  | 4.26  | 5.61  | 3.97  | 5.23  | 3.57   | 4.82  |
| 7.62 (300")  | 4.572 | 6.096  | 5.14  | 6.76  | 4.79  | 6.30  | 4.31   | 5.78  |
| 8.89 (350")  | 5.334 | 7.112  | 6.01  | 7.90  | 5.60  | 7.37  | 5.04   | 6.74  |
| 10.16 (400") | 6.096 | 8.128  | 6.88  | 9.04  | 6.42  | 8.43  | 5.78   | 7.71  |
| 12.70 (500") | 7.620 | 10.160 | 8.63  | 11.33 | 8.05  | 10.57 | 7.25   | 9.63  |
| 15.24 (600") | 9.144 | 12.192 | 10.37   | 13.62 | 9.67  | 12.70 | 8.72   | 11.39 |

## Appendix / Annexe / 付録 (continued / suite / つづき)

### Note

- A ±5 % error in listed projection distances may occur.  
In addition, when [KEYSTONE] is used, distance is corrected to become smaller than the specified screen size.
- The throw ratio is based on the value during projection with the projected image size of 5.08 m (200").
- The periods used in the numbers in the tables are decimal points.

### Remarque

- Une erreur de ±5 % dans des distances de projection énumérées peut se produire.  
En outre, lorsque [CORRECTION DE TRAPÈZE] est utilisé, la distance est corrigée pour devenir inférieure à la taille d'écran spécifiée.
- Le rapport de projection est basé sur la valeur en cours de projection avec une taille de l'image projetée de 5,08 m (200").
- Les points utilisés dans les nombres dans les tableaux sont des points décimaux.

### お知らせ

- 記載の投写距離は±5%以下の範囲内で誤差が発生します。  
また、[台形補正] 使用時は、所定の画面サイズよりも小さくなる方向で補正されます。
- スローレシオは、投写画面サイズ 200 型投写時の値を基準にしています。

Setting-up dimensions which are not given in the above table can be calculated using the formulas below. Check the projected image size SD (m) and use the following formula to determine projection distance (L).

La configuration des dimensions qui ne sont pas données dans le tableau ci-dessus peut être calculée à l'aide des formules suivantes. Vérifiez la taille de l'image projetée SD (m) et utilisez la formule suivante pour déterminer la distance de projection (L).

上記の表以外の投写寸法は次の計算式で求めることができます。画面対角サイズ SD (m) をご確認のうえ、それぞれの計算式で投写距離 (L) を求めてください。

## Appendix / Annexe / 付録 (continued / suite / つづき)

- Projection distance formulas
- Formules de distance de projection
- 投写距離計算式

The dimensions of the following table contain a slight error.

Periods are used to represent decimal points in the calculation formulas in the following table.

Les dimensions du tableau suivant peuvent présenter un léger écart.

Les points sont utilisés pour indiquer les décimales dans les formules de calcul dans le tableau suivant.

次の表内の寸法は若干の誤差があります。

- ET-D3LEU100

(Unit / Unités / 単位 : m)

|   |   | L                   |
|---|---|---------------------|
| PT-RQ22K /<br>PT-RQ32K /<br>PT-RQ13K  | When the screen aspect ratio is 16:10<br>Lorsque le rapport d'aspect de l'écran est 16:10<br>アスペクト比 16:10 のとき | =0.3497 × SD-0.0664 |
|   | When the screen aspect ratio is 16:9<br>Lorsque le rapport d'aspect de l'écran est 16:9<br>アスペクト比 16:9 のとき    | =0.3594 × SD-0.0664 |
|   | When the screen aspect ratio is 4:3<br>Lorsque le rapport d'aspect de l'écran est 4:3<br>アスペクト比 4:3 のとき       | =0.3959 × SD-0.0664 |
| PT-RZ21K /<br>PT-RZ31K /<br>PT-RZ12K /<br>PT-DZ21K2 /<br>PT-DZ13K /<br>PT-DZ10K | When the screen aspect ratio is 16:10<br>Lorsque le rapport d'aspect de l'écran est 16:10<br>アスペクト比 16:10 のとき | =0.3264 × SD-0.0664 |
|   | When the screen aspect ratio is 16:9<br>Lorsque le rapport d'aspect de l'écran est 16:9<br>アスペクト比 16:9 のとき    | =0.3355 × SD-0.0664 |
|   | When the screen aspect ratio is 4:3<br>Lorsque le rapport d'aspect de l'écran est 4:3<br>アスペクト比 4:3 のとき       | =0.3695 × SD-0.0664 |
| PT-RS20K /<br>PT-RS30K /<br>PT-RS11K /<br>PT-DS20K2 /<br>PT-DS12K               | When the screen aspect ratio is 16:9<br>Lorsque le rapport d'aspect de l'écran est 16:9<br>アスペクト比 16:9 のとき    | =0.3631 × SD-0.0664 |
|   | When the screen aspect ratio is 4:3<br>Lorsque le rapport d'aspect de l'écran est 4:3<br>アスペクト比 4:3 のとき       | =0.3334 × SD-0.0664 |
| PT-DW17K2 /<br>PT-DW11K   | When the screen aspect ratio is 16:9<br>Lorsque le rapport d'aspect de l'écran est 16:9<br>アスペクト比 16:9 のとき    | =0.3723 × SD-0.0664 |
|   | When the screen aspect ratio is 4:3<br>Lorsque le rapport d'aspect de l'écran est 4:3<br>アスペクト比 4:3 のとき       | =0.4558 × SD-0.0664 |
| PT-DZ16K2   | When the screen aspect ratio is 16:9<br>Lorsque le rapport d'aspect de l'écran est 16:9<br>アスペクト比 16:9 のとき    | =0.3355 × SD-0.0664 |
|   | When the screen aspect ratio is 4:3<br>Lorsque le rapport d'aspect de l'écran est 4:3<br>アスペクト比 4:3 のとき       | =0.4105 × SD-0.0664 |

## Appendix / Annexe / 付録 (continued / suite / つづき)

### ● ET-D3LEW200

(Unit / Unités / 単位 : m)

|                        |   | L                   |                     |
|------------------------|---|---------------------|---------------------|
|                        |   | LW                  | LT                  |
| PT-RQ22K /<br>PT-RQ32K | When the screen aspect ratio is 16:10<br>Lorsque le rapport d'aspect de l'écran est 16:10<br>アスペクト比 16:10 のとき | =0.6070 × SD-0.1001 | =0.7956 × SD-0.1076 |
|                        | When the screen aspect ratio is 16:9<br>Lorsque le rapport d'aspect de l'écran est 16:9<br>アスペクト比 16:9 のとき    | =0.6239 × SD-0.1001 | =0.8177 × SD-0.1076 |
|                        | When the screen aspect ratio is 4:3<br>Lorsque le rapport d'aspect de l'écran est 4:3<br>アスペクト比 4:3 のとき       | =0.6872 × SD-0.1001 | =0.9007 × SD-0.1076 |
| PT-RZ21K /<br>PT-RZ31K | When the screen aspect ratio is 16:10<br>Lorsque le rapport d'aspect de l'écran est 16:10<br>アスペクト比 16:10 のとき | =0.5665 × SD-0.1001 | =0.7425 × SD-0.1076 |
|                        | When the screen aspect ratio is 16:9<br>Lorsque le rapport d'aspect de l'écran est 16:9<br>アスペクト比 16:9 のとき    | =0.5823 × SD-0.1001 | =0.7632 × SD-0.1076 |
|                        | When the screen aspect ratio is 4:3<br>Lorsque le rapport d'aspect de l'écran est 4:3<br>アスペクト比 4:3 のとき       | =0.6414 × SD-0.1001 | =0.8406 × SD-0.1076 |
| PT-RS20K /<br>PT-RS30K | When the screen aspect ratio is 16:9<br>Lorsque le rapport d'aspect de l'écran est 16:9<br>アスペクト比 16:9 のとき    | =0.6303 × SD-0.1001 | =0.8262 × SD-0.1076 |
|                        | When the screen aspect ratio is 4:3<br>Lorsque le rapport d'aspect de l'écran est 4:3<br>アスペクト比 4:3 のとき       | =0.5787 × SD-0.1001 | =0.7584 × SD-0.1076 |

# MEMO

---

## Panasonic Corporation

Web Site : <https://panasonic.net/cns/projector/>

---

### Panasonic System Solutions Company of North America

Two Riverfront Plaza, Newark, NJ 07102

TEL: (877) 803 - 8492

### Panasonic Canada Inc.

5770 Ambler Drive, Mississauga, Ontario L4W 2T3

TEL: (905) 624 - 5010

---

## パナソニック株式会社 コネクティッドソリューションズ社

〒 571-8503 大阪府門真市松葉町2番15号 電話 ☎ 0120-872-601